LEROY®

CLEANING KIT

61 3115

LEROY Pens should always be cleaned after use or at the end of the day's work. If ink is allowed to dry in the pen it may clog the point and impede the flow, or damage the pin (plunger).

LEROY Pens are most conveniently cleaned as follows:

1. Remove the pins from the tubes.
2. Soak both parts in the bottle of LEROY Cleaning Fluid, in one of the plastic sieves provided. If the ink has been allowed to dry, the pins and tubes should be left in the fluid overnight.
3. Lift the sieve out of the Cleaning Fluid and tip the pen parts into the other sieve, rinsing them in the other bottle filled with clean water, or under running water.
4. Tip the parts out of the sieve and blow out any remaining water or particles of dried ink from the tubes, with the nozzle of the rubber bulb held against their top openings.
5. Reassemble the pen parts. If several pens of various sizes are cleaned at the same time, the corresponding parts can be readily identified by the size numbers stamped both on the top of the pins and on the tubes.

LEROY Cleaning Fluid is sold separately in 2 oz. bottles 61 3117 and in quart bottles (61 3120).

For information regarding the complete line of LEROY Lettering and Symbol Drawing Templates and other LEROY equipment, ask your K&E Distributor or any K&E Branch, or write to Keuffel & Esser Co. Hoboken, N. J. for the booklet "LEROY Lettering and Symbols".

KEUFFEL & ESSER CO.

NEW YORK : HOBOKEN, N. J.

PHILADELPHIA • DETROIT • CHICAGO • MILWAUKEE • ST. LOUIS • DALLAS
HOUSTON • DENVER • SAN FRANCISCO • LOS ANGELES • SEATTLE
ANCHORAGE • TORONTO • MONTREAL

COPYRIGHT 1950 KEUFFEL & ESSER CO.

G20-1

PRINTED IN U.S.A.